LF 75

Spare parts list

Forward plate

s/n BGF000001-
Engine: Honda GX 160



© 2014 Construction Tools PC AB | No. 9800112201d| 2016-02

General information

This spare parts list applies to the following:

Part number	Description
3382 0000 22	Forward plate LF 75 Honda L 420 mm (16.55 in.)
3382 0000 23	Forward plate LF 75 Honda LAT 420 mm (16.55 in.)
3382 0000 24	Forward plate LF 75 Honda L 500 mm (19.68 in.)
3382 0000 21	Forward plate LF 75 Honda LAT 500 mm (19.68 in.)

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.
Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

Instructions for use
This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.
For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.
Please observe the safety instructions listed in the relevant Safety and operating instructions!

Contents

Kits and consumables 1

Spare parts list

Engine plate installation, Honda 3
Ground plate installation 5
Block paving plate 420 mm (16.5 in.) 7
Block paving plate 500 mm (19.7 in.) 9
Lifting handle 11
Transport device, old version 13
Transport device, new version 15
Sprinkler system 17
Fork lifting device 19
Engine installation, Honda 21
Engine, Honda GX 160 UT2 SXS4 OH 23
Transmission cover, Honda 26
Standard handle, old version 29
Standard handle for Honda, new version 31
Vibration damped handle 33
Labels 35

Kits

One year service kit, Honda 37
Shock absorber repair kit 39
Eccentric element repair kit 41
Block paving plate kit 420 mm (16.5 in.) 43
Block paving plate kit 500 mm (19.7 in.) 45
Transport device kit 47
Sprinkler system kit 49
Fork lifting device kit 51
Vibration damped handle kit 53

Kits and consumables

Service offers resume LF75	Item	Description
Lubricants	1	PAROIL E Mission Green
	2	PAROIL E Mission Green
	3	PAROIL E Mission Green
Preventive maintenance	4	One year service kit
Rebuild / Overhaul kits	5	Complete handle kit devibrated
	6	Complete handle kit std.
	7	Transport device kit
Wear&Repair Kits	8	Eccentric element repair kit
	9	Shock absorber repair kit

Item	Part No.	Name	Qty	L
1	1630047100	Can Paroil E Mission Green 5 Liter/1.32 Gallon	1	
2	1630047200	Can Paroil E Mission Green 20 Liter/5.3 Gallon	1	
3	1630047300	Container Paroil E Mission Green 1000 Liter/264.1 Gallon	1	
4	3382100001	One year service kit	1	
5	3382100182	Vibration damped handle kit	1	
6	3382100181	Complete handle kit std.	1	
7	3382100179	Transport device kit	1	
8	3382100004	Eccentric element repair kit	1	
9	3382100006	Shock absorber repair kit	1	

Spare parts list Engine plate installation, Honda



Item	Part No.	Name	Qty	L
1	4700902041	Screw, M8x25mm 8.8 A2K	7	
2	3382010126	Protective frame	1	
3	3382010132	Cover	1	
4	3382010135	Engine plate	1	
5	4700792725	Square taper washer	2	A

Comments for Page: Engine plate installation, Honda

A: Flat machined surface. B: Round machined surface.

(L)OCAL REMARKS

A | For engine plate with flat machined contact surface for washers.

Spare parts list Ground plate installation



Item	Part No.	Name	Qty	L
1	4812070452	Ground plate, 420 mm, 16.5 in.	1	
2	4812070447	Ground plate, 500 mm, 19.7 in.	1	
3	4812070058	Eccentric shaft	1	
4	4700792711	Ball bearing	2	
5	4700396548	Cover	1	
6	0666600090	Lip-type oil seal	1	
7	4700395013	V-belt pulley	1	
8	0300013055	Washer, 8.4 x 16 x 1.5 mm, 0.33 x 0.63 x 0.06 in. 300 HV	1	
9	0147300074	Screw, M8 x 25 mm 8.8 A2K	1	
10	0147124603	Screw	6	
11	4700396549	Cover	1	
12	4700282373	Shock absorber	4	
13	4700570103	Nut, M10 x 1.5 mm GEOMET®	8	A
14	4812070664	Sprinkler bar, 420 mm, 16.5 in.	1	
15	4812070663	Sprinkler bar, 500 mm, 19.7 in.	1	
16	4700902286	Lock nut, M8x1.25 mm A2K	3	
17	4700500023	Screw, M8x40 mm 8.8 A2K	2	
18	4700500025	Screw, M8x50 mm 8.8 A2K	1	
19	0333520018	Lock washer	6	

Comments for Page: Ground plate installation

GEOMET is a registered trademark of Nof Metal Coatings North America Inc.

Spare parts list Block paving plate 420 mm (16.5 in.)



Item	Part No.	Name	Qty	L
1	4700394043	Polyurethane plate, 420 mm, 16.5 in.	1	
2	4700394044	Bracket	1	
3	4700903586	Nut, M8 x 1.25 mm A2K	2	
4	4700904229	Washer, 8.4x 6x1.5 mm 300HV	2	
5	4700791762	Screw, M8 x 75 mm 8.8 A2K	2	

Spare parts list Block paving plate 500 mm (19.7 in.)



Item	Part No.	Name	Qty	L
1	4700394046	Polyurethane plate, 500 mm, 19.7 in.	1	
2	4700394047	Bracket	1	
3	4700903586	Nut, M8 x 1.25 mm A2K	2	
4	4700904229	Washer, 8.4x 6x1.5 mm 300HV	2	
5	4700791762	Screw, M8 x 75 mm 8.8 A2K	2	

Spare parts list Lifting handle



Item	Part No.	Name	Qty	L
1	4700395018	Handle	1	A
2	4700395020	Handle	1	B
3	4700500505	Screw, M8x20 mm 8.8 A2K	4	

Comments for Page: Lifting handle

(L)OCAL REMARKS

A | Right

B | Left

Spare parts list Transport device, old version



Item	Part No.	Name	Qty	L
1	3382010141	Fork	1	
2	4700383582	Wheel	2	
3	4700601003	Washer, 8,4x25x2 mm	4	
4	4700394103	Lock	2	
5	3382010139	Bracket	1	A
6	3382010140	Bracket	1	B
7	4700902147	Screw, M8 x 35 mm 8.8	4	
8	4700500018	Hex. screw	2	
9	4700902285	Nut	8	C
10	4700500075	Screw, M6-1,0x25 mm 8.8	4	
11	4700921028	Pipe clamp	4	
12	4812070210	Stop	2	
13	4700500503	Screw, M6x30 mm 8.8 A2K	4	
14	4700902286	Lock nut, M8x1.25 mm A2K	2	
15	4700500506	Screw, M8x30 mm 8.8 A2K	2	

Comments for Page: Transport device, old version

(L)OCAL REMARKS

A | Left

B | Right

C | M 6

Spare parts list Transport device, new version



Item	Part No.	Name	Qty	L
1	4812070394	Bracket	1	A
2	4812070396	Bracket	1	B
3	4700601003	Washer, 8,4x25x2 mm	4	
4	4812070395	Fork	1	
5	4700500506	Screw, M8x30 mm 8.8 A2K	2	
6	4700902286	Lock nut, M8x1.25 mm A2K	2	
7	4700383582	Wheel	2	
8	4700500018	Hex. screw	2	
9	4700385387	Shock absorber	1	
10	4812070471	Hook	1	
11	4700902287	Nut, M10	1	
12	4700904230	Plain washer 10.5x22x2 mm	1	
13	4700500048	Screw, M10x20 mm 8.8 A3K	1	
14	4700902041	Screw, M8x25mm 8.8 A2K	4	

Comments for Page: Transport device, new version

(L)OCAL REMARKS

A | left

B | Right

Spare parts list Sprinkler system



Item	Part No.	Name	Qty	L
1	3382010125	Water tank	1	
2	3382100335	Valve rod, complete	1	
3	0663211969	O-ring, 15 x 4 mm	1	
4	-	Valve rod	1	
5	0663211970	O-ring, 8 x 2.5 mm	1	
6	4700500013	Screw, M6x16 mm 8.8 A2K	1	
7	4700601003	Washer, 8,4x25x2 mm	2	
8	4700791182	Nut, M8 -8 DIN985	1	
9	4700393381	Label	1	
10	4700392092	Cap	1	
11	4700500021	Screw, M8x25 mm 8.8 A2K	1	
12	4700928381	Washer, 6.4x18x1.6 mm	1	
13	4700392073	Handle	1	

Spare parts list Fork lifting device



Item	Part No.	Name	Qty	L
1	4700396194	Strap	2	
2	4700902041	Screw, M8x25mm 8.8 A2K	4	
3	4700615103	Washer, 9 x 25 x 3 mm, 0.35 x 0.98 x 0.12 in.	8	
4	4700902286	Lock nut, M8x1.25 mm A2K	4	

Spare parts list Engine installation, Honda



Item	Part No.	Name	Qty	L
1	4700281125	Engine, Honda GX160UT2 SXS4 SD	1	A
2	4700904734	Washer, 8.4x26x4 mm 300 HV	4	
3	4700393903	Washer	4	
4	4700500508	Screw, M8x50 mm 8.8 A2K	4	
5	4700902286	Lock nut, M8x1.25 mm A2K	4	
6	4700396126	Stiffener	1	
7	4700792774	Blind rivet, 6.4 x 12 mm , 0.25 x 0.47 in.	1	
8	4700902041	Screw, M8x25mm 8.8 A2K	1	
9	4700904734	Washer, 8.4x26x4 mm 300 HV	1	
10	4700391706	Centrifugal clutch	1	
11	4700395658	V-belt	1	

Comments for Page: Engine installation, Honda

(L)OCAL REMARKS

A | Honda GX160UT2 SXS4 SD

Spare parts list Engine, Honda GX 160 UT2 SXS4 OH



Item	Part No.	Name	Qty	L
1	4700281125	Engine, Honda GX160UT2 SXS4 SD	1	
2	3382100163	Silencer	1	
3	3382100168	Gasket	1	
4	4700239063	Gasket, muffler	1	
5	3382100167	Spark plug	1	
6	3382100165	Oil dipstick, complete	1	
7	3382100166	Gasket	1	
8	4700937917	Valve cover	1	
9	4700238301	Gasket	1	
10	3382100174	Fuel cap	1	
11	3382100173	Fuel tank	1	
12	3382100172	Engine switch	1	
13	4700238302	Oil plug	1	
14	4700238303	Gasket oil plug	1	
15	--	Engine part	1	
16	4700937049	Gasket	1	
17	3382100164	Carburetor	1	
18	4700939659	Spacer	1	
19	4700239771	Nut	1	
20	4700239685	Cover	1	
21	4700239771	Nut	1	
22	4700239772	Grommet	1	
23	4700239323	Air filter, complete	1	A
24	4700938230	Air filter housing	1	
25	4700239060	Muffler cover, upper	1	
26	4700239065	Recoil starter, cpl	1	B, E
27	4700239381	Screw	1	
28	4700239380	Guide	1	
29	4700239378	Ratchet	2	B
30	4700239377	Spring	2	
31	4700239379	Friction spring	1	B
32	4700239376	Reel	1	
33	---	Housing	1	
34	4700239375	Spring	1	
35	4700239391	Handle	1	
36	4700239374	Starter rope	1	
37	3382100176	Recoil starter, complete	1	C, D
38	3382100177	Adjustment screw	1	C

Item	Part No.	Name	Qty	L
39	4700239380	Guide	1	
40	3382100169	Ratchet	2	C
41	4700239377	Spring	2	
42	3382100170	Friction washer	1	C
43	3382100171	Reel	1	C
44	---	Housing	1	
45	4700239375	Spring	1	
46	4700239391	Handle	1	
47	4700239374	Starter rope	1	
48	3382100175	Friction spring	1	J

Comments for Page: Engine, Honda GX 160 UT2 SXS4 OH

(L)OCAL REMARKS

A | Delivered with outer and inner filter.

B | Valid up to engine serial number 1411005.

C | Valid from engine serial number 1411006.

D | Black

E | Red

This page intentionally left blank

Spare parts list Transmission cover, Honda



Item	Part No.	Name	Qty	L
1	3382010130	Belt guard, inner	1	
2	4700393325	Belt guard, outer	1	
3	0147300074	Screw, M8 x 25 mm 8.8 A2K	3	
4	4700903586	Nut, M8 x 1.25 mm A2K	1	
5	0147300050	Screw, M8 x 30 mm 8.8 A2K	3	
6	4812070368	Screw, M8 x 25 mm 8.8 A2K	1	
7	4812070431	Lock spring	1	
8	4812070364	Washer	3	
9	0147300049	Screw, M8 x 20 mm 8.8 A2K	2	

Comments for Page: Transmission cover, Honda

(L)OCAL REMARKS

A | Outer

B | Inner

Spare parts list Standard handle, old version



Item	Part No.	Name	Qty	L
1	3382010120	Handle	1	A
2	3382010121	Handle	1	B
3	3382010122	Handle	1	
4	4700393220	Link	2	
5	4700394029	Cover	2	
6	4700394145	Spacer sleeve	2	
7	4700394228	Washer	2	
8	4700792508	Screw, M6 x 40 mm A2K	6	
9	4700791182	Nut, M8 -8 DIN985	4	
10	4700792497	Disc spring, 18 x 8.2 x 1 mm, 0.71 x 0.32 x 0.04 in.	4	
11	4700901928	Screw, M12 x 50 mm 8.8 A3K	2	
12	4700391821	Sleeve bearing	2	
13	4700391822	Shock absorber	2	
14	4700792597	Spirol pin, 5 x 25 mm, 0.20 x 0.98 in.	2	

Comments for Page: Standard handle, old version

(L)OCAL REMARKS

A | Left

B | Right

Spare parts list Standard handle for Honda, new version



Item	Part No.	Name	Qty	L
1	4700508032	Screw, M12 x 50 mm 8.8 A3K , See section "Handle, standard".	2	
2	4812070733	Sleeve	2	
3	4700391822	Shock absorber	2	
4	4812070717	Handle	1	
5	4812070718	Handle	1	A
6	4812070721	Bracket	2	
7	4812070719	Sleeve	2	
8	4812070720	Knob	2	
9	4700904281	Washer, 5,3x10x1 300HV	2	
10	4700150001	Retainer ring, 4.8 x 7 x 0.6 mm, 0.18 x 0.26 x 0.02 in.	2	

Comments for Page: Standard handle for Honda, new version

(L)OCAL REMARKS

A | Upper

Spare parts list Vibration damped handle



Item	Part No.	Name	Qty	L
1	4700792783	Washer, 6.4x18x1.6 mm A2T	16	
2	4700393079	Bracket	2	
3	4700391824	Shock absorber	2	
4	4700393078	Bracket	2	
5	4700792496	Screw, M5 x 10 mm A2K	8	
6	4700792406	Jointing nut, M6 x 30 mm 8.8	8	
7	4700792784	Screw, M6 x 12 mm 10.9 A2T	16	
8	4700391826	Handle	1	A
9	3382011179	Handle	1	B

Comments for Page: Vibration damped handle

(L)OCAL REMARKS

A | Old version

B | New version, use together with new standard handles.

Spare parts list Labels



Item	Part No.	Name	Qty	L
1	4700394704	Label, start instruction	1	A
2	3382010040	Product label "Atlas Copco"	2	B
3	3382010194	Product label	1	C
4	3382010190	Product label	1	D
5	4700394708	Instruction label	1	E
6	4700791290	Noise level label	1	
7	-	Drive screw	4	
8	-	Dataplate (Not available separately)	1	
9	3382010151	Product label	1	F
10	4700357587	Label lifting point	1	G

Comments for Page: Labels

(L)OCAL REMARKS

A | Start instruction

B | "Atlas Copco"

C | "LF 75"

D | "LF 75"

E | Assembly

F | "LF 75"

G | Lift point

Kits One year service kit, Honda

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	3382100599	200 Hours Service Kit / 12 Months Service Kit	1	
1	4700239323	Air filter, complete	1	
2	4700238303	Gasket oil plug	1	
3	4700395658	V-belt	1	
4	4700239374	Starter rope	1	
5	4700924842	Spark plug	1	
6	4700238301	Gasket	1	
7	4700239323	Air filter, complete	1	

Kits Shock absorber repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	3382100006	Shock absorber repair kit	1	
2	4700282373	Shock absorber	4	A
3	4700792725	Square taper washer	4	B
4	4700792817	Hexagon nut with flange	8	
5	4700391822	Shock absorber	2	C
6	4700508032	Screw, M12 x 50 mm 8.8 A3K , See section "Handle, standard".	2	

Comments for Page: Shock absorber repair kit

(L)OCAL REMARKS

A | For ground plate

See section "Ground plate installation".

B | See section "Ground plate installation".

C | For handle

See section "Handle, standard".

Kits Eccentric element repair kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	3382100004	Eccentric element repair kit	1	
2	4700902041	Screw, M8x25mm 8.8 A2K	1	
3	4700904640	Washer, 8.4x22x3 mm 300HV	1	
4	4700163105	Lip-type oil seal	1	A
5	4700792119	Screw, M6x16 mm 8.8 A2K	6	
6	4700792711	Ball bearing	2	B

Comments for Page: Eccentric element repair kit

(L)OCAL REMARKS

A | See section "Ground plate installation".

B | See section "Ground plate installation".

Kits Block paving plate kit 420 mm (16.5 in.)



Item	Part No.	Name	Qty	L
1	4812070171	Block paving plate kit	1	
1	4700394043	Polyurethane plate, 420 mm, 16.5 in.	1	
2	4700394044	Bracket	1	
3	4700903586	Nut, M8 x 1.25 mm A2K	2	
4	4700904229	Washer, 8.4x 6x1.5 mm 300HV	2	
5	4700791762	Screw, M8 x 75 mm 8.8 A2K	2	

Kits Block paving plate kit 500 mm (19.7 in.)



Item	Part No.	Name	Qty	L
1	4812070172	Block paving plate kit	1	
2	4700394046	Polyurethane plate, 500 mm, 19.7 in.	1	
3	4700394047	Bracket	1	
4	4700903586	Nut, M8 x 1.25 mm A2K	2	
5	4700904229	Washer, 8.4x 6x1.5 mm 300HV	2	
6	4700791762	Screw, M8 x 75 mm 8.8 A2K	2	

Kits Transport device kit



Item	Part No.	Name	Qty	L
1	3382100179	Transport device kit	1	
2	4812070394	Bracket	1	A
3	4812070396	Bracket	1	B
4	4700601003	Washer, 8,4x25x2 mm	4	
5	4812070395	Fork	1	
6	4700500506	Screw, M8x30 mm 8.8 A2K	2	
7	4700902286	Lock nut, M8x1.25 mm A2K	2	
8	4700383582	Wheel	2	
9	4700500018	Hex. screw	2	
10	4700385387	Shock absorber	1	
11	4812070471	Hook	1	
12	4700902287	Nut, M10	1	
13	4700904230	Plain washer 10.5x22x2 mm	1	
14	4700500048	Screw, M10x20 mm 8.8 A3K	1	
15	4700902041	Screw, M8x25mm 8.8 A2K	4	
16	-	Screw, M8 x 35 mm 8.8 A2K	4	

Comments for Page: Transport device kit

(L)OCAL REMARKS

A | Left

B | Right

Kits Sprinkler system kit



Item	Part No.	Name	Qty	L
1	3382010215	Sprinkler system kit	1	
2	3382010125	Water tank	1	
3	3382100335	Valve rod, complete	1	
4	4700392073	Handle	1	
5	4700601003	Washer, 8,4x25x2 mm	2	
6	4700500021	Screw, M8x25 mm 8.8 A2K	1	
7	4700791182	Nut, M8 -8 DIN985	1	
8	4700928381	Washer, 6.4x18x1.6 mm	1	
9	4700500013	Screw, M6x16 mm 8.8 A2K	1	
10	4700392092	Cap	1	
11	4700393381	Label	1	
12	3382010092	Label	1	

Kits Fork lifting device kit



Item	Part No.	Name	Qty	L
1	4812070173	Fork lifting device kit	1	
2	4700396194	Strap	1	
3	4700902041	Screw, M8x25mm 8.8 A2K	4	
4	4700615103	Washer, 9 x 25 x 3 mm, 0.35 x 0.98 x 0.12 in.	8	
5	4700902286	Lock nut, M8x1.25 mm A2K	8	

Kits Vibration damped handle kit



Item	Part No.	Name	Qty	L
1	3382100182	Vibration damped handle kit	1	
2	4700393079	Bracket	2	
3	4700792406	Jointing nut, M6 x 30 mm 8.8	8	
4	4700792784	Screw, M6 x 12 mm 10.9 A2T	16	
5	4700391824	Shock absorber	2	
6	4700393078	Bracket	2	
7	3382011179	Handle	1	
8	4700792496	Screw, M5 x 10 mm A2K	8	
9	4700792783	Washer, 6.4x18x1.6 mm A2T	16	

Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.